



NOTE: REQUIRED DOOR UNDERCUT IS 1/4 FROM FINISHED FLOOR OR 1/8 FROM THRESHOLD

- NOTE 1: FOR SELF-TAPPING SCREWS: DRILL 1/8 DIA HOLE (4 PLCS)
 FOR SEX BOLTS: REFER TO NOTE 2 FOR DRILL HOLE SIZES.
- NOTE 2: UNLESS OTHERWISE SPECIFIED, FOR HOLLOW METAL DOOR: 4 HOLES ON OUTSIDE OF DOOR ARE 3/8 INCH DIAMETER AND INSIDE OF DOOR ARE 7/32 INCH DIAMETER. FOR WOOD DOOR: 4 HOLES 3/8 INCH DIAMETER THRU.
- NOTE 3: WHEN BAR HEIGHT IS 36" OR MORE, DIVIDE BAR HEIGHT BY 2. OTHERWISE, USE 18" AS THE DIMENSION.
- NOTE 4: FOR 3100T AND 3100W OMIT THE 4 LOWER MOUNTING HOLES FROM DOOR PREPARATION.
- NOTE: IT IS RECOMMENDED THE MOUNTING HOLES BE PREPARED IN THE FIELD.

DIM A	DOOR OPENING WIDTH			
	30"	36"	42"	48"
	24 1/4	30 1/4	36 1/4	42 1/4

RHR PREPARATION SHOWN.
 SEE 10011 FOR LHR.

ADAMS RITE MANUFACTURING COMPANY CITY OF INDUSTRY, CA 91749	3100 SVR FIRE RATED RHR EXIT DEVICE WOOD OR HOLLOW METAL DOOR		
PART NO. 80-0180-81T	NOTE: SEE MASTER SHEET 10001 FOR SUGGESTED REINFORCEMENT	TEMPLATE NO.: 10010-2	DATE: 03/20/97